



INSTRUCTIONS FOR ICE FOG COMPACT

1. Remove the front cover, if needed use the 5" flexible hose placed in the cover.
2. Open the back door.
3. Screw the CO2 hose (gauge side) in the liquid CO2 bottle (50 lbs or 75 lbs), equipped with a siphon / dip tube. (Do not forget to put the white plastic washer)
4. Screw the other side of the CO2 hose in the brass bulkhead inside the generator.
5. Open the CO2 valve.
6. To fill the fluid reservoir, disconnect unit before adding Fog Fluid. If it is pressurized, depressurize the reservoir by turning OFF the pressure switch located on the back panel of the generator. Unscrew the brass cap and pour the MDG LOW FOG FLUID until it reaches the inside bottom of the opening. Avoid overfilling, screw back the closure and make sure it is hand tightened. Turn back ON the pressure switch.
7. Plug the AC cord 115V or 230V, depending on the voltage of the generator.
8. Plug the remote control in the connector.
9. Place the fog delay potentiometer knob at maximum.
10. Press the Power switch on the remote control, a red LED will turn on. Then a yellow LED will turn ON indicating "HEAT ON".
11. Wait 5 to 6 minutes until the green Ready LED turns on.
12. The generator is now ready to operate.
13. Press the Smoke switch: During the fog delay (approximately 30 seconds), only the CO2 will come out. This is to cool down the cooling chamber of the generator. After 25 to 30 seconds, the fog output will start.

If you have any technical questions, please call 514-272-6040 or 800-663-3020 to speak to a technician. Or send an e-mail to: info@mdgfog.com

Warranty

When installed and operated as recommended, MDG Fog Generators Ltd. Guarantees that this product will remain free of defects in parts and labor for a period of two (2) years from the moment it is delivered.

This warranty does not apply if the product has been modified without our written authorization, or repaired without a written authorization from MDG or one of its authorized service center, or if it is used under conditions for which it has not been designed, or if a non MDG Low Fog Fluid has been used. MDG Fog Generators Ltd is not responsible for any damages resulting from a faulty installation or from abusive use of the product.

If any device is found unsatisfactory under the terms of this warranty, MDG Fog Generators Ltd will repair or replace it free of all charges except transportation costs.

This warranty applies only to the product itself and MDG Fog Generators Ltd declines responsibility for any losses, costs, or damages resulting from its use.

MDG Fog Generators Ltd shall not be liable for consequential damage in case of any failure to meet the conditions of any warranty or shipping schedule, nor will claims for labor, loss of profits, repairs, or other expenses incidental to replacement be allowed.

The repair or replacement of the product, by MDG Fog Generators Ltd shall constitute fulfillment of all obligations to the purchaser.

No other guarantees or warranties, expressed or implied, are made by MDG Fog Generators Ltd in connection with its products. This warranty is nontransferable and applies to the original purchaser only.

To obtain satisfaction under the terms of this warranty, contact your local sales office, and we will be pleased to help you.